

4-Serial/1-Parallel Port PCI Adapter

User Manual

Ver. 2.00

**All brand names and trademarks are properties of their
respective owners.**

Features and Benefits

Features	<ul style="list-style-type: none">● Compliant with PCI Local Bus Specification Revision 2.3● Supports 4 x UART serial port● Add one IEEE 1284 Parallel Port on system● Easy Plug and Play● Automatically selects IRQ & I/O address● Built-in 16C450/550 compatible UART● Data transfer rate up to 115200 bps● Supports Standard Parallel Port (SPP), Enhanced Parallel (EPP) & Enhanced Capability Port (ECP)● Parallel data transfer rate up to 1.5 Mbytes/sec
Bus	<ul style="list-style-type: none">● PCI 32-bit
Connectors	<ul style="list-style-type: none">● 4 x DB9 male serial connectors● 1 x DB25 female parallel connector

System Requirements

- Windows® XP/Vista/7 (32/64 bit)

- Available PCI slot

Package Contents

- 1 x 4-Serial/1-Parallel Port PCI Adapter
- 1 x Bracket with two DB9 male serial ports
- 1 x Bracket with one DB25 female parallel port
- 1 x Driver CD
- 1 x User Manual

Note: Contents may vary depending on market/region.

Hardware Installation

1. Turn off the power to your computer.
2. Unplug the power cord and remove your computer's cover.
3. Remove the slot bracket from an available PCI slot.
4. To install the card, carefully align the card's bus connector with the selected PCI slot on the motherboard. Push the board down firmly.
5. Replace the slot bracket's holding screw to secure the card.
6. Replace the computer cover and reconnect the power cord.

Driver Installation

Put the driver CD in your CD-ROM drive. The CD-ROM will start automatically. Click “Install Driver” to start the installation. Follow the instructions on screen to install the driver. After driver installation is complete, you must restart your computer.

To Verify Driver Installation

1. Right click **My Computer**, then click **Manage**. Click **Device Manager**.
2. Click on the +(plus sign) in front of **Ports(COM & LPT)**, two **High-Speed PCI Serial Port ...** ,two **PCI-ISA Communication Port ...** and one **PCI-ISA Parallel Port ...** should be displayed.